

# **RESEARCH ARTICLE**

# Estimation of Delay Times in Coupling Between Autonomic Regulatory Loops of Human Heart Rate and Blood Flow Using Phase Dynamics Analysis

Vladimir S Khorev<sup>1</sup>, Anatoly S Karavaev<sup>1,2</sup>, Elena E Lapsheva<sup>1</sup>, Tatyana A Galushko<sup>1</sup>, Mikhail D Prokhorov<sup>2</sup> and Anton R Kiselev<sup>1,3,4,\*</sup>

<sup>1</sup>Department of Dynamic Modeling and Biomedical Engineering, Saratov State University; 83, Astrakhanskaya str., Saratov, 410012, Russia

<sup>2</sup>Saratov Branch of the Institute of Radio Engineering and Electronics of Russian Academy of Sciences, 38, Zelyonaya str, Saratov; 410019, Russia

<sup>3</sup>Department of New Cardiological Informational Technologies, Research Institute of Cardiology, Saratov State Medical University n.a. V.I. Razumovsky; 112, Bolshaya Kazachya str, Saratov, 410012, Russia

<sup>4</sup>Department of Surgical Treatment for Interactive Pathology, Bakulev Scientific Center for Cardiovascular Surgery; 135, Rublevskoe Shosse, Moscow, 121552, Russia

Received: June 30, 2017

Revised: November 24, 2017

Accepted: December 17, 2017

# Abstract:

# **Objective:**

We assessed the delay times in the interaction between the autonomic regulatory loop of Heart Rate Variability (HRV) and autonomic regulatory loop of photoplethysmographic waveform variability (PPGV), showing low-frequency oscillations.

# Material and Methods:

In eight healthy subjects aged 25–30 years (3 male, 5 female), we studied at rest (in a supine position) the simultaneously recorded two-hour signals of RR intervals (RRIs) chain and finger photoplethysmogram (PPG). To extract the low-frequency components of RRIs and PPG signal, associated with the low-frequency oscillations in HRV and PPGV with a frequency of about 0.1 Hz, we filtered RRIs and PPG with a bandpass 0.05-0.15 Hz filter. We used a method for the detection of coupling between oscillatory systems, based on the construction of predictive models of instantaneous phase dynamics, for the estimation of delay times in the interaction between the studied regulatory loops.

#### Results:

Averaged value of delay time in coupling from the regulatory loop of HRV to the loop of PPGV was  $0.9\pm0.4$  seconds (mean  $\pm$  standard error of the means) and averaged value of delay time in coupling from PPGV to HRV was  $4.1\pm1.1$  seconds.

#### Conclusion:

Analysis of two-hour experimental time series of healthy subjects revealed the presence of delay times in the interaction between regulatory loops of HRV and PPGV. Estimated delay time in coupling regulatory loops from HRV to PPGV was about one second or even less, while the delay time in coupling from PPGV to HRV was about several seconds. The difference in delay times is explained by the fact that PPGV to HRV response is mediated through the autonomic nervous system (baroreflex), while the HRV to PPGV response is mediated mechanically via cardiac output.

\* Address correspondence to this author at the Department of Dynamic Modeling and Biomedical Engineering, Saratov State University; 83, Astrakhanskaya str., Saratov, 410012, Russia; Tel: 845-2393978; E-mail: kiselev@cardio-it.ru

Keywords: Cardiovascular system, Autonomic regulation, Coupling analysis, Phase dynamics, Delay time.

#### **1. INTRODUCTION**

Autonomic regulation of the cardiovascular system plays a crucial role in providing its functioning under various conditions [1]. At the same time, healthy status corresponds to a balance of activity of various regulatory loops during their complex interaction. Failure of autonomic regulation under the influence of external factors is associated with the development of various pathological conditions, for example, hypertension [2]. As it has been shown in our previous studies [3, 4], the peculiarities of interaction between the autonomic regulatory loops are sensitive markers of cardiovascular pathologies, and their results are very promising for the development of diagnostic methods [4 - 6]. Such studies are important for obtaining fundamental knowledge of structure and mechanisms of the cardiovascular autonomic regulation in healthy subjects and patients with cardiovascular diseases. The development of nonlinear methods for the analysis and signal processing of complex systems has opened up opportunities for investigating complex collective dynamics of regulatory systems and studying the connections between them.

In this study, a promising method for diagnostics of coupling between oscillatory systems, based on the construction of predictive models of instantaneous phase dynamics, is used for the assessment of delay times in the interaction between the autonomic regulatory loop of heart rate variability (HRV) and autonomic regulatory loop of photoplethysmographic waveform variability (PPGV), showing low-frequency oscillations with a basic frequency of about 0.1 Hz. For the first time, such research is carried out for long records of healthy subjects, containing more than 700 characteristic periods. The employment of long records allowed us to improve the statistical properties of estimates for the calculated indices and make new conclusions about the peculiarities of the considered regulatory loops.

## 2. MATERIAL AND METHODS

#### 2.1. Data Source

This study was approved by the Ethics Committee of the Saratov State Medical University n.a. V.I. Razumovsky in Saratov, Russia, and informed consent was obtained from all participants. We studied eight healthy subjects (five female and three male) aged 25–30 years. The two-hour signals of electrocardiogram (ECG) and photoplethysmogram (PPG) measured on the middle finger of the left hand were simultaneously recorded with one multichannel measurement system (psychophysiological telemetric system "Rehacor-T" with standard sensor package, Medicom MTD Ltd, Taganrog, Russia) in all subjects in a supine position. The PPG was recorded using an optical sensor of reflected light in the infrared range (wavelength is about 960 nm). A standard sensor was used, which is a part of the certified serial multichannel measurement system.

The subjects were studied at rest (in a supine position) in the morning under spontaneous breathing. All signals were sampled at 250 Hz and digitized at 14 bits. From ECG signal, an RR intervals (RRIs) chain, representing a sequence of time intervals between the R-peaks of ECG, was extracted. To obtain equidistant time series from unequidistant RRIs chain, we approximate it with cubic splines and resample with a frequency of 5 Hz. Time series were processed following the recommendations for the standardization and interpretation of the electrocardiogram [7]. Special methods of artifact reduction were not applied.

To extract the low-frequency components of RRIs and PPG signal, associated with the low-frequency oscillations in HRV and PPGV with a frequency of about 0.1 Hz [8], we filtered RRIs and PPG signal by a filter with the bandpass 0.05-0.15 Hz. In previous experiments, in which the subjects were breathing with a linearly increasing frequency, we revealed the self-oscillatory nature of regulatory processes, generating the low-frequency oscillations in PPGV and HRV [9]. In the present paper, regulatory loops of HRV and PPGV were also considered as self-oscillating processes interacting with each other, with delays in coupling.

### 2.2. Signal Processing

To analyze the coupling between the signals of regulatory loops, we used a method based on the modeling of phase dynamics [10 - 13]. The main idea of the method is to evaluate how much the future evolution of the phase of one system depends on the current phase value of another system. If taking into account the dynamics of the first system, reduces the prediction error of the model for the individual dynamics of the second system, then the first system has an influence on the second system. Let us calculate at first the instantaneous phases  $\varphi(t)$  of analyzed signals x(t) (RRIs or PPG) as follows:

$$\varphi(t) = \arctan \frac{y(t)}{x(t)},\tag{1}$$

where y(t) is the Hilbert transform of x(t),

$$x^{*}(t) = \int_{-\infty}^{+\infty} \frac{x(\tau)}{\pi(t-\tau)} d\tau .$$
<sup>(2)</sup>

Using the time series of instantaneous phases  $\varphi_1(t)$  and  $\varphi_2(t)$ , we construct the following predictive models:

$$\Delta \varphi_1(t) = F_1(\varphi_1(t), \varphi_2(t) + \varepsilon_1(t)),$$
  

$$\Delta \varphi_2(t) = F_2(\varphi_2(t), \varphi_1(t) + \varepsilon_2(t)),$$
(3)

where  $\Delta \varphi_k(t) = \varphi_k(t+\tau) - \varphi_k(t)$ , k = 1, 2, are the increments of instantaneous phases within the prediction interval  $\tau$ ,  $\varepsilon_k(t)$  are the white Gaussian noises, and  $F_k$  are trigonometric polynomials:

$$F_{1}(\phi_{1},\phi_{2},\mathbf{a}_{1}) = \alpha_{0}^{(1)} + \sum_{m,n} \left( \alpha_{m,n}^{(1)} \cos(m\phi_{1} - n\phi_{2}) + \beta_{m,n}^{(1)} \sin(m\phi_{1} - n\phi_{2}) \right),$$

$$F_{2}(\phi_{2},\phi_{1},\mathbf{a}_{2}) = \alpha_{0}^{(2)} + \sum_{m,n} \left( \alpha_{m,n}^{(2)} \cos(m\phi_{2} - n\phi_{1}) + \beta_{m,n}^{(2)} \sin(m\phi_{2} - n\phi_{1}) \right),$$
(4)

where  $\mathbf{a}_k = (\alpha_0^{(k)}, \{\alpha_{m,n}^{(k)}\}, \{\beta_{m,n}^{(k)}\})$  is a vector of coefficients, k = 1, 2. The range of summation, i.e. the indices *m* and *n*, determining which terms are present in the polynomial, can be different for systems 1 and 2 [10]. The coefficients  $J_{1,2}$ , characterizing the coupling strength for different *D* values, where *D* is a time shift between the signals, can be estimated as follows:

$$J_{1,2} = \frac{1}{2\pi^2} \int_{0}^{2\pi} \int_{0}^{2\pi} \left( \frac{\partial F(\varphi_{1,2}(t), \varphi_{2,1}(t-D), \mathbf{a_{1,2}})}{\partial \varphi_{1,2}} \right)^2 d\varphi_1 d\varphi_2 \,.$$
(5)

We used the following parameters of the method in this paper: n = m = 1 [11]. The estimation of the coefficients  $J_{1,2}$  was accompanied by the calculation of a 95% confidence interval using the analytical formula proposed in Ref [12]. If  $J_{1,2}$  and its confidence interval is greater than zero, then the coupling between the studied systems is believed to be statistically significant. The presence of local maxima in the dependence  $J_{1,2}(D)$  indicates the presence of delay D in coupling between the systems [11].

The signals of RRIs and PPG from healthy subjects with duration of 120 minutes were analyzed in a moving window. The width of moving window was 20 minutes (about 120 characteristic periods of oscillations) and the window shift was 10 minutes. In each window, the coefficients  $J_{1,2}(D)$  were calculated. The value of D was varied in the range from zero to ten seconds. The dependences  $J_{1,2}(D)$  were statistically significant greater than zero and, as a rule, showed several local maxima, which can be associated with both a delay in interaction and fluctuations caused by the influence of noise, artifacts and various interferences. To reduce the effect of such fluctuations, we averaged the results of data analysis for each of the windows.

## **3. RESULTS**

Typical results of coupling estimation between the regulatory loop of HRV and regulatory loop of PPGV are shown in Fig. (1) for one of the subjects (#5). Here and below, the subscript 1 corresponds to the direction of coupling regulatory loops from HRV to PPGV (Fig. 1a), while subscript 2 corresponds to the direction of coupling from PPGV to HRV (Fig. 1b). The dependence  $J_1(D)$  in Fig. (1a) has a pronounced maximum for the trial delay  $D_{max}$ =1.2 s. For the opposite direction of coupling in Fig. (1b), the maximum of  $J_{1,2}(D)$  is located at  $D_{max}$ =5.2 s.

The  $D_{\text{max}}$  values for both directions of coupling are shown in Fig. (2) for all subjects. Subjects #2–#6 have delay time in coupling from the regulatory loop of HRV to the regulatory loop of PPGV either close to zero or significantly smaller than delay time in coupling from PPGV to HRV (Fig. 2a). Subject #8 has close delay times in both directions. For subject #1, the delay time in coupling from the loop of HRV to the loop of PPGV is greater than delay time in the opposite direction.



**Fig. (1).** Dependences of coupling coefficients on trial delay time for subject #5 for the case of coupling from regulatory loop of HRV to regulatory loop of PPGV (a) and the case of coupling from PPGV to HRV (b).



**Fig. (2).** (a) Estimations of delay times for each of the eight subjects. (b) Delay times averaged over the subjects (mean  $\pm$  standard error of the means). Delay times in coupling from regulatory loop of HRV to regulatory loop of PPGV are shown by circles and delay times in coupling from PPGV to HRV are shown by crosses.

Fig. (2b) shows the results of average delay times over the subjects. Averaged value of delay times in coupling regulatory loops from HRV to PPGV is  $4.1\pm1.1$  seconds (data presented as mean  $\pm$  standard error of the means). This value is significantly greater than the averaged value of delay times in coupling from HRV to PPGV, which is equal to  $0.9\pm0.4$  seconds.

We revealed no dependence of our results on gender and age of studied subjects.

# 4. DISCUSSION

The methods of coupling detection based on the analysis of phase dynamics are highly sensitive in the case of weak coupling, but require long time series. The employment of short time series (less than 100 characteristic periods) leads to a large fluctuation in the estimates of coupling strength and delay and to biases of such estimates [13]. Therefore, interpretation of the results of signal analysis in living systems requires a special care, since the dynamics of these systems is characterized by a change of their parameters in time and the signals of the systems are noisy and usually have artifacts. Moreover, it is often difficult or even impossible to obtain experimental signals of sufficient duration for technical and ethical reasons.

Surprisingly, few research works have been devoted to the study of delay times between the elements of the cardiovascular system. One of them explains the biophysical origin of 0.1 Hz oscillations in the HRV as a result of

#### 20 The Open Hypertension Journal, 2017, Volume 9

baroreflex regulation of blood pressure. Blood pressure oscillations with the characteristic period about 10 seconds are caused mostly by sympathetic modulation of vascular resistance that acts as a stimulus for the baroreceptors [14]. The baroreflex responds to blood pressure amplification with heart rate decline and vasodilatation, which, in turn, produces a decrease in blood pressure. Vaschillo *et al.* [15] proved the delay in blood pressure changes following heart rate change every five seconds at average, thus yielding the ubiquitous oscillation of about 10 seconds in HRV. Taking into account that oscillations in blood supply in digital arteries contribute significantly to the photoplethysmographyc signal in fingers [16], we can be sure that it is possible to study the regulation of systemic blood pressure using PPGV.

A number of studies are known, in which the elements of autonomous regulation of blood circulation are described in the form of closed-loop delayed feedback systems [17 - 19]. The importance of having a closed feedback loop for the stable functioning of the circuits of autonomous regulation of blood circulation is emphasized in some papers [20, 21]. At the same time, such organization of autonomic regulatory loops does not exclude the presence of delays in couplings between the individual closed-loop delayed feedback systems. For example, similar architecture of interactions within the multi-element system is often taken into account in studies of higher nervous activity [22]. Considering that, we assume that BPV and HRV processes can be considered as self-oscillatory closed-loop systems, with the time-delays in the information pathways between these systems.

In our previous study [23], the presence of delayed coupling between the regulatory loops of HRV and PPGV has been shown during the analysis of 10-minute records from healthy subjects and patients with myocardial infarction, and conclusion has been made in favor of the presence of a predominant direction of coupling from HRV to PPGV.

In the present study, considerably longer records from healthy subjects were analyzed (more than 700 characteristic oscillation periods for each subject versus 60 periods in the study [23]). As a result, we significantly reduced the fluctuations in the estimates of coefficients  $J_{1,2}$  in comparison with earlier studies. It allowed us to assess the delay times in coupling with an accuracy of about one second. The obtained results show that the impact of low-frequency oscillations in HRV on similar oscillations in PPGV resulted in a small delay, since the delay time in coupling is usually less than one second. The delay time in coupling from the regulatory loop of PPGV to the regulatory loop of HRV was observed to be much longer and its averaged value was observed to be about four seconds. The difference in delay times can be explained by the fact that PPGV to HRV response is mediated through the autonomic nervous system (baroreflex), while the HRV to PPGV for subjects #1 and #8 were probably the result of measurement noise and artifacts.

Previously Cevese *et al.* [24] with the help of cross-spectral analysis showed the presence of negative phase shift between RRIs and systolic blood pressure, which indicated a 1–2 seconds lag in heart period changes in relation to pressure. In our study, we obtained larger delay times in coupling from the regulatory loop of PPGV to HRV. This can be explained by the higher accuracy of the estimates provided by the nonlinear analysis method we used [25, 26].

However, despite few studies, the delays between the regulation loops of heart rate and blood pressure, which we investigated through PPGV analysis, remain briefly studied. We assume that the estimates of delay times in the interaction between the elements of the autonomic regulatory system may be potentially useful in studying some autonomic dysfunctions and other diseases. For example in another paper [27], the authors showed that the delays between blood pressure and heart rate in patients with end-stage kidney disease increased in renal insufficiency.

#### CONCLUSION

Analysis of two-hour experimental time series of healthy subjects revealed the presence of different delay times in the interaction between the regulatory loops, showing low-frequency oscillations in HRV and PPGV. The delay time in coupling from the regulatory loop of HRV to the regulatory loop of PPGV is about one second, while the delay time in coupling in the opposite direction is about several seconds. This difference in delay times can be explained by the fact that PPGV to HRV response is mediated through the autonomic nervous system (baroreflex), while the HRV to PPGV response is mediated mechanically via cardiac output.

#### ETHICAL APPROVAL AND CONTENT TO PARTICIPATE

This study was approved by the Ethics Committee of the Saratov State Medical University n.a. V.I. Razumovsky in Saratov, Russia. We studied eight healthy subjects (five female and three male) aged 25–30 years.

# HUMAN AND ANIMAL RIGHTS

No animals were used in this research. All research procedures followed were in accordance with the ethical standards of the committee responsible for human experimentation (institutional and national), and with the Helsinki Declaration of 1975, as revised in 2008 (http://www.wma.net/en/20activities/10ethics/10helsinki/)

# **CONSENT FOR PUBLICATION**

Informed consent was obtained from all participants.

#### **CONFLICT OF INTEREST**

The authors declare no conflict of interest, financial or otherwise.

### ACKNOWLEDGEMENTS

This work was supported by Russian Science Foundation, grant No. 14-12-00291 (nonlinear analysis of coupling), and by the President of the Russian Federation, grant No. MD-3318.2017.7 (physiological experiment).

#### REFERENCES

- [1] Guyton AC, Hall JE. Textbook of medical physiology. 13<sup>th</sup> ed. Elsevier 2016.
- [2] Wein AM, Ed. Autonomic dysfunction: clinical features, treatment, diagnosis. Moscow, Russia: Med. Inf. Agency 2000.
- Karavaev AS, Prokhorov MD, Ponomarenko VI, *et al.* Synchronization of low-frequency oscillations in the human cardiovascular system. Chaos 2009; 19(3): 033112.
   [http://dx.doi.org/10.1063/1.3187794] [PMID: 19791992]
- [4] Kiselev AR, Karavaev AS, Gridnev VI, et al. Method of estimation of synchronization strength between low-frequency oscillations in heart rate variability and photoplethysmographic waveform variability. Russ Open Med J 2016; 5: e0101. [http://dx.doi.org/10.15275/rusomj.2016.0101]
- [5] Kiselev AR, Gridnev VI, Prokhorov MD, et al. Evaluation of 5-year risk of cardiovascular events in patients after acute myocardial infarction using synchronization of 0.1-Hz rhythms in cardiovascular system. Ann Noninvasive Electrocardiol 2012; 17(3): 204-13. [http://dx.doi.org/10.1111/j.1542-474X.2012.00514.x] [PMID: 22816539]
- [6] Kiselev AR, Gridnev VI, Prokhorov MD, *et al.* Selection of optimal dose of beta-blocker treatment in myocardial infarction patients based on changes in synchronization between 0.1 Hz oscillations in heart rate and peripheral microcirculation. J Cardiovasc Med (Hagerstown) 2012; 13(8): 491-8.

[http://dx.doi.org/10.2459/JCM.0b013e3283512199] [PMID: 22343262]

- [7] Kligfield P, Gettes LS, Bailey JJ, et al. Recommendations for the standardization and interpretation of the electrocardiogram: Part I: The electrocardiogram and its technology: a scientific statement from the American Heart Association Electrocardiography and Arrhythmias Committee, Council on Clinical Cardiology; the American College of Cardiology Foundation; and the Heart Rhythm Society: endorsed by the International Society for Computerized Electrocardiology. Circulation 2007; 115(10): 1306-24. [PMID: 17322457]
- [8] Bernardi L, Leuzzi S, Radaelli A, Passino C, Johnston JA, Sleight P. Low-frequency spontaneous fluctuations of R-R interval and blood pressure in conscious humans: A baroreceptor or central phenomenon? Clin Sci 1994; 87(6): 649-54. [http://dx.doi.org/10.1042/cs0870649] [PMID: 7874855]
- [9] Karavaev AS, Kiselev AR, Gridnev VI, et al. Phase and frequency locking of 0.1-Hz oscillations in heart rate and baroreflex control of blood pressure by breathing of linearly varying frequency as determined in healthy subjects. Hum Physiol 2013; 39: 416-25. [http://dx.doi.org/10.1134/S0362119713010040]
- [10] Rosenblum MG, Pikovsky AS. Detecting direction of coupling in interacting oscillators. Phys Rev E Stat Nonlin Soft Matter Phys 2001; 64(4 Pt 2): 045202.

[http://dx.doi.org/10.1103/PhysRevE.64.045202] [PMID: 11690077]

- [11] Smirnov DA, Karpeev IA, Bezruchko BP. Detection of coupling between oscillators from their short time series: Condition of applicability of the method of phase dynamics modeling. Tech Phys Lett 2007; 33: 147-50. [http://dx.doi.org/10.1134/S1063785007020162]
- [12] Smirnov DA, Sidak EV, Bezruchko BP. A method for revealing coupling between oscillators with analytical assessment of statistical significance. Tech Phys Lett 2013; 39: 601-5. [http://dx.doi.org/10.1134/S1063785013070110]
- [13] Smirnov DA. Characterization of weak coupling between self-oscillation systems from short time series: Technique and applications. J Commun Technol Electron 2006; 51: 534-44. [http://dx.doi.org/10.1134/S106422690605007X]
- [14] Montano N, Gnecchi-Ruscone T, Porta A, Lombardi F, Malliani A, Barman SM. Presence of vasomotor and respiratory rhythms in the

discharge of single medullary neurons involved in the regulation of cardiovascular system. J Auton Nerv Syst 1996; 57(1-2): 116-22. [http://dx.doi.org/10.1016/0165-1838(95)00113-1] [PMID: 8867094]

- [15] Vaschillo E, Lehrer P, Rishe N, Konstantinov M. Heart rate variability biofeedback as a method for assessing baroreflex function: A preliminary study of resonance in the cardiovascular system. Appl Psychophysiol Biofeedback 2002; 27(1): 1-27. [http://dx.doi.org/10.1023/A:1014587304314] [PMID: 12001882]
- [16] Rhee S, Yang BH, Asada H. Theoretical evaluation of the influence of displacement on finger photoplethysmography for wearable health monitoring sensors. Mechanical Engineering Congress and Exposition. Nashville, TN. 1999.
- [17] Madwed JB, Albrecht P, Mark RG, Cohen RJ. Low-frequency oscillations in arterial pressure and heart rate: A simple computer model. Am J Physiol 1989; 256(6 Pt 2): H1573-9.
   [PMID: 2735430]
- [18] Ottesen JT. Modelling of the baroreflex-feedback mechanism with time-delay. J Math Biol 1997; 36(1): 41-63. [http://dx.doi.org/10.1007/s002850050089] [PMID: 9440304]
- [19] Fowler AC, McGuinness MJ. A delay recruitment model of the cardiovascular control system. J Math Biol 2005; 51(5): 508-26. [http://dx.doi.org/10.1007/s00285-005-0339-1] [PMID: 16012798]
- [20] Burgess DE, Hundley JC, Li SG, Randall DC, Brown DR. First-order differential-delay equation for the baroreflex predicts the 0.4-Hz blood pressure rhythm in rats. Am J Physiol 1997; 273(6 Pt 2): R1878-84. [PMID: 9435640]
- [21] Ringwood JV, Malpas SC. Slow oscillations in blood pressure via a nonlinear feedback model. Am J Physiol Regul Integr Comp Physiol 2001; 280(4): R1105-15.
   [PMID: 11247833]
- [22] McIntosh AR. Mapping cognition to the brain through neural interactions. Memory 1999; 7(5-6): 523-48. [http://dx.doi.org/10.1080/096582199387733] [PMID: 10659085]
- [23] Kiselev AR, Khorev VS, Gridnev VI, et al. Interaction of 0.1-Hz oscillations in heart rate variability and distal blood flow variability. Hum Physiol 2012; 38: 303-9.
   [http://dx.doi.org/10.1134/S0362119712020107] [PMID: 22830248]
- [24] Cevese A, Gulli G, Polati E, Gottin L, Grasso R. Baroreflex and oscillation of heart period at 0.1 Hz studied by alpha-blockade and crossspectral analysis in healthy humans. J Physiol 2001; 531(Pt 1): 235-44. [http://dx.doi.org/10.1111/j.1469-7793.2001.0235j.x] [PMID: 11179406]
- [25] Bezruchko BP, Smirnov DA. Extracting knowledge from time series: An introduction to nonlinear empirical modeling. Springer 2010. [http://dx.doi.org/10.1007/978-3-642-12601-7]
- [26] Tass P, Smirnov D, Karavaev A, et al. The causal relationship between subcortical local field potential oscillations and Parkinsonian resting tremor. J Neural Eng 2010; 7(1): 16009. [http://dx.doi.org/10.1088/1741-2560/7/1/016009] [PMID: 20083863]
- [27] Sapoznikov D, Rubinger D. Delayed effect of blood pressure fluctuations on heart rate in patients with end-stage kidney disease. Med Biol Eng Comput 2011; 49(9): 1045-55. [http://dx.doi.org/10.1007/s11517-011-0806-3] [PMID: 21755317]

© 2017 Khorev et al.

This is an open access article distributed under the terms of the Creative Commons Attribution 4.0 International Public License (CC-BY 4.0), a copy of which is available at: https://creativecommons.org/licenses/by/4.0/legalcode. This license permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited.